

BOMBERS EQUESTRIAN EQUIPMENT

TROUBLESHOOTING!

To allow the ball to come out of the net quicker - or to speed up your net, loosen knot **B** and reduce the distance between **A** and **B** and lengthen the distance **B** to **C**.

Equal adjustments are necessary on both sides of the net.

To stop the ball from coming out of the net too quickly, reverse the above.

If more adjustment is required to slow down your net, loosen knot **B** and shorten the distance between

D and **B** and lengthen the distance **B** to **E**.

Equal adjustments are necessary on both sides of the net.

PLEASE NOTE: ADJUSTMENTS SHOULD BE MADE ONLY A MILLIMETRE AT A TIME!

Knots must be secured back into their original configuration.

Please do not hesitate to contact us if you are experiencing any further problems.

